

Enviro W1 Washroom Bactericidal Cleaner



When dosing concentrate chemicals always use the recommended PPE, and always read the labels to check best practice for handling both the undiluted & ready to use solutions.

Product Usage Guide





BB451-1

enviro

00

W1 Washroom

Bacterioidal Cleaner

Health & Safety

Please refer to relevant

COSHH Safety Data Sheet



Passes EN 1276 EN 14476, EN 1650 EN 16615 & EN 16777 at 1:60



Use appropriate (
PPE as indicated in the Safety Data Sheet and place Safety Signs.



Close cap, invert the bottle for a few seconds. Turn the bottle upright & dosing cap is primed with 10ml of solution.



Add 1 x 10ml from dosing cap to 600ml of water in trigger spray bottle.



Gently shake to mix.



5 Spray onto cloth and wipe surface.
Contact time 1 minute for EN 1276,
EN 16615.5 minutes
for EN 1650.



Once dry remove Safety Signs.

Damp Mopping and General Cleaning



Use appropriate (
PPE as indicated in the Safety Data Sheet and place Safety Sians.



Close cap, invert the bottle for a few seconds. Turn the bottle upright & dosing cap is primed with 10ml of solution.



Add 2x 10ml from dosing cap to 1 litre of water in a bucket.



Mop or wipe surface.



6 Allow to air dry.



Remove Safety Signs





